# **Meet The Beck**

**SLQ Wiki Fabrication Lab 2024/04/17 13:06** 

SLQ Wiki 2/21 Meet The Beck

# **Meet The Beck**



## **Materials**

- 8 Pan head M3 15mm machine screws (a)
- 8 Hex Nyloc Nuts (b)
- 6 Pan head M2 8mm machine screws ( c )
- 6 Pan head M2 Nuts (d)

SLQ Wiki 3/21 Meet The Beck




- 3 9g micro servo motors (e)
- 3 Servo Arms (f)
- 3 self tapping screws to suit servo motor arms (g)




- 1 Arduino Nano (h)
- battery holder for 3AA cells with adaptor board attached (i)

SLQ Wiki 4/21 Meet The Beck



- 2 leg parts (type I without slot) (j)2 leg parts (type II with slot) (k)



- 2 foot tops (I)
- 2 foot soles (m)



- one counter-balance shaft (n)
- two cross-pieces (with holes) (o)
- two braces (p)
- one servo mount (q)



#### **Tools**


- laser cut M3 spanner
- Philips head screwdriver
- Acrylic glue or Super Glue
- soldering iron and solder.

SLQ Wiki 6/21 Meet The Beck

## **Instructions**

#### **Step One**

Peel off all paper coating on acrylic pieces.




# **Step Two**

Glue the etched and un-etched foot shaped pieces (I + M) together with the etched side facing out.

SLQ Wiki 7/21 Meet The Beck




Repeat this process for the right foot, Note: the two un-etched pieces are identical.




## **Step Three**

Grab a servo (e) a insert a smaller M2 screw (c) on the side without the cord.

SLQ Wiki 8/21 Meet The Beck




Loosely add a nut(d) so that the thread is just visible on both sides.




Slip one of the Typel legs (j) over the screw and nut. This may require some jiggling as the nut must align to get into the hole.

SLQ Wiki 9/21 Meet The Beck




Tighten the screw until the nut is held in place.




Repeat this process for the other side of the servo.

SLQ Wiki 10/21 Meet The Beck



Take care to thread the electrical cord through the slot provided on the leg.



Repeat for the other servo.

### **Step Five**

Attach the nylon servo (f) arm to the servo (g) using a smaller screw ( c ) and nut (d). Make sure the screw heads are on the same side as the servo arm.

SLQ Wiki 11/21 Meet The Beck



Push the screw all the way into the feet.




Attach the servo arm to the feet as shown below.

SLQ Wiki 12/21 Meet The Beck




**Step Six** 

Put an M3 screw into a cross-piece.




Push the screw into the hole furthest from the leg, on the wireless side of the servo.

SLQ Wiki 13/21 Meet The Beck




Add a nyloc nut and tighten using a screw driver and the small spanner provided.




Fit the servo mount, with the servo arm facing inwards to the same leg.

SLQ Wiki 14/21 Meet The Beck




On the other leg, attach a cross-piece to the hole closest to the servo.




Fit the counter-balance to the last hole.

SLQ Wiki 15/21 Meet The Beck




Its time to attach the second servo. Make sure the cord is on the same side, then mount it the same way.




Glue the two braces across the legs for extra support.

SLQ Wiki 16/21 Meet The Beck



# **Step Seven - Electronics**

Solder the three coloured wires to the arduino nano' connecting them to D9,D10,D11 on the arduino.




Trim off any excess wire.

SLQ Wiki 17/21 Meet The Beck




Connect the servos to the adaptor board headers. Take care to connect the brown wire from the servos to the black wire on the apdator board.


Make sure to connect the center servo to wire connected to D11 (in this case the yellow wire).



The legs move in sync so they both may be connected to either pin D9 or D10

SLQ Wiki 18/21 Meet The Beck






Place the batteries into the battery holder briefly until the servo's move then stop.

This correctly aligns the servos for final construction.

SLQ Wiki 19/21 Meet The Beck




Press and screw on the feet so they are aligned perpendicular to the servos.




Now the center servo can be attached. Try to keep the frame as square as possible

SLQ Wiki 20/21 Meet The Beck




the battery holders boards and wires can then be taped to the counter-balance shaft.



They act as a counter-weight. This may need some adjustment to find the optimum height.

SLQ Wiki 21/21 Meet The Beck





<hidden>